



NOTES:

- (MEMBER) = FURNISHED & INSTALLED BY MEMBER. (PRVEPA) = FURNISHED & INSTALLED BY PRVEPA.
- MEMBER RESPONSIBLE FOR BLOCKING OUT FOOTING AND OR SLAB CONDUIT UNDERNEATH METER PRIOR TO POURING CONCRETE, (SEE DETAIL "B")
- CONDUIT FROM METER INTO GROUND MUST BE STRAIGHT WITHOUT BENDS AROUND OR OVER CONCRETE, FOOTER, OR OBSTACLE. (SEE DETAIL "B")
- HORIZONTAL CONDUIT(S) MUST BE BURIED A MINIMUM OF 3 FT.
- VERTICAL CONDUIT-SCHEDULE 80; HORIZONTAL CONDUIT-SCHEDULE 40.
- ALL CONDUIT JOINTS MUST BE GLUED WATER TIGHT.
- NO MORE THAN TWO(2) 45 OR ONE(1) 90 DEGREE BENDS ARE PERMITTED IN HORIZONTAL CONDUITS BETWEEN METER AND PRVEPA EQUIPMENT.

OVERHEAD ASSEMBLY

- MEMBER RESPONSIBLE FOR FURNISHING & INSTALLING TEMPORARY METER POLE WITHIN 10 FT. OF TRANSFORMER LOCATION. (SEE TEMPORARY METER POLE INSTALLATION GUIDE)
- TEMPORARY POLE AND WIRING SHALL COMPLY WITH THE MOST CURRENT NATIONAL ELECTRIC CODE (NEC) INCLUDING ARTICLE 305 AND ANY OTHER LOCAL CODE.
- GROUND FAULT PROTECTION FOR PERSONNEL ON CONSTRUCTION SITES SHALL BE PROVIDED TO COMPLY WITH THE NEC. ALL 125 VOLT, SINGLE PHASE, 15 AND 20 AMP RECEPTACLE OUTLETS THAT ARE IN USE BY PERSONNEL SHALL HAVE GROUND FAULT CIRCUIT INTERRUPTER (GFCI) PROTECTION.



UNDERGROUND SERVICE GUIDE
OVERHEAD TO UNDERGROUND
PRVEPA-103

REV	LTR	DATE	DESCRIPTION	APPR
REVISIONS				
J:\SPEC\epa103.dwg 2/3/2004 3:55:39 PM by DB				